


# ELECTROAFILADORA BF-200-ML



## LISTA DE RECAMBIOS ELECTROAFILADORA BF-200-ML

NO	NAME	QTY.	NO	NAME	QTY.
1	Left outer guard	1	31	screw	4
2	Nut	1	32	Switch plate	1
3	Nameplate of wheel	4	33	screw	2
4	Wheel	2	34	Switch	1
5	Wheel flange	4	35	Base	1
6	Guard belt	2	36	Base plate	1
7	Left Inner guard	1	37	drawer	1
8	Cover	2	38	screw	4
9	screw	1	39	screw	4
10	Stator	1	40	Rubber foot	4
11	Motor housing	1	41	drawer plate	1
12	Bearing	2	42	screw	2
13	Middle ring	1	43	Capacitor	1
14	Rotor	1	44	screw	1
15	Nut	16	45	Left tool Rest	1
16	Spring washer	22	46	screw	6
17	Flat washer	16	47	Plug & Cord	1
18	Right Inner guard	1	48	Cable bushing	1
19	Spark guard	2	49	Cable pressure clump	1
20	screw	2	50	Cable pressure plate	1
21	Nut	1	51	screw	1
22	screw	6	52	Handle	2
23	Right outer guard	1	53	Eyeshield bracket	2
24	Right tool Rest	1	54	Square neck screw	2
25	Knob nut	2	55	pressure plate	2
26	screw	1	56	Eyeshield	2
27	Dentate washer	1	57	Lamp	1
28	Ground terminal	1	58	Nut	2
29	Flat washer	9	59	transformer	1
30	Spring washer	9	60	screw	1