



LISTADO RECAMBIOS

Parts No.	Description	Quantity	Parts No.	Description	Quantity
01	right support	1	44	working table	1
02	hexagon bolt M10X25	12	45	column nut 8X40	2
03	Washer 20	24	46	hexagon bolt M10X50	2
04	Nut M10	12	47	spring plate	2
05	support connector	1	48	spring plate	2
06	left support	1	49	hexagon bolt M8X25	2
07	spring	1	50	Washer 8	4
08	Bearing 205	2	51	press plate	2
09	left seat	1	52	Nut M8	2
10	hexagon bolt M10X25	8	53	hexagon bolt M10X70	2
11	column nut 5X20	4	54	hexagon bolt M10X60	2
12	block ring 25	2	55	Washer 10	2
13	shaft	1	56	back gauge seat	1
14	screw	2	57	Bolt M6X20	4
15	Bearing 102	2	58	back gauge	1
16	bearing fixer	2	59	back gauge body	1
17	Screw M6X5	2	60	press holder	1
18	column nut 6X40	2	61	spring	1
19	gear wheel	2	62	Bolt M10X30	6
20	hook	1	63	blade	1
21	pull ring	1	64	handle	1
22	handle	1	65	hexagon bolt M8X25	1
23	shaft seat	1	66	Nut M8	2
24	hexagon bolt M6X20	2	67	blade seat	1
25	spring fixer	1	68	pivot body	1
26	Nut M12	1	69	hexagon bolt M6X50	6
27	flat pin 5X14	1	70	rotary handle	1
28	handle wheel	1	71	column nut 8X30	2
29	rotary handle M10	1	72	hexagon bolt M10X25	2
30	spring washer 6	1	73	press bar M6X50	1
31	hexagon bolt M6X15	1	74	nut	1
32	flat washer 6	1	75	bush	1
33	tooth bar	2	76	bolt	1
34	limiting bar	1	77	hexagon bolt M8X45	1
35	Bolt M6X20	3	78	Nut M20	2
36	column nut 5X10	2	79	bush	1
37	right seat	1	80	press body	1
38	limiting block	1	81	shaft	1
39	hexagon bolt M8X45	2	82	screw	1
40	Bolt M10X30	6	83	bush	1
41	lower blade	1	84	handle	1
42	Bolt M6X20	4	85	hexagon bolt M8X25	2
43	Nut M6	3			